
DANCOVER®

Manual for Pergola Gazebo 3x3,6m

3x3.6m User Manual



	REF	QTY	REF	QTY	REF	QTY
Carton 1/4	A	4PCS		4PCS	J	4PCS
	K	47PCS	C	1PC	M	48PCS
	N	4PCS	0	24PCS	P	96PCS
	Q	96PCS	R	12PCS	S	27PCS
					V	1PC
	W	16PCS	X	1PC	Y	2PCS
	User Manual	1SET				
Carton 2/4	B1	1PC	B2	1PC	C	2PCS
	<u>(G</u>	1PC	H	1PC		
Carton 3/4	Ф	12PCS				
Carton 4/4	D	11PCS				


REF	PICTURE	QTY
A		4PCS
B 1		1PC
B2		1PC
(O)		2PCS
0		23PCS
G		1PC
Ξ		1PC


REF	PICTURE	QTY
\ominus		4PCS
\bigcirc		4PCS
(S)		47PCS
		1PC
(\(\S\))		48PCS
(Z)		4PCS
0		24PCS
P	(4))))))) M5x12mm	96PCS
Q	4.2x25mm	96PCS


REF	PICTURE	QTY
R	5.5x19mm	12PCS
S		27PCS
\Diamond		1PC
(\$)		16PCS
\otimes		1PC
Y		2PCS


Warning


In snow season or in case of snow forecast open up your shutters in vertical position to avoid any damaging on your pergola.




































Make the shutter as vertical.









DANCOVER



Contact information

Austria



Belgium



Croatia



Denmark



Estonia



Finland



France



Germany



Ireland



Italy



Latvia



Lithuania



Nederland



Norway



Poland



Portugal



Spain



Sweden



Switzerland



UK

